

[2019-August-NewHigh Quality Braindump2go 700-070 Exam Dumps 60Q Free Share[Q23-Q34

August/2019 Braindump2go 700-070 Exam Dumps with PDF and VCE New Updated Today! Following are some new 700-070

real exam questions:1.|2019 Latest Braindump2go 700-070 Exam Dumps (PDF & VCE) Instant

Download:<https://www.braindump2go.com/700-070.html>2.|2019 Latest Braindump2go 700-070 Exam Questions & Answers Instant

Download:<https://drive.google.com/drive/folders/1P54oN5tDiFWKHgozwB-G-dxgBS0t7fnT?usp=sharing>QUESTION 23What can

cause the tables to appear warped?A. Cables to the displays are installed incorrectly.B. Parts or screws in the table assembly are installed incorrectly.C. The room contains too manycontrasting colors.D. The table is placed too close to the screens.**Answer: D**

QUESTION 24Where can you find packet-transmission statistics?A. Monitoring > MaintenanceB. Monitoring > Network Data C. Monitoring > StatisticsD. Monitoring > Call Info**Answer: B**

Explanation:Use the Network Data section to view packet transmission statistics collected from the network. Data is listed in columns labeled as if you were looking at the back of the system. For example, on an IX5000, the labels would indicate statistics from the left, center, and right codecs.To monitor network statistics:

In the Monitoring page, scroll down to Network Data. Your network data appears

http://www.cisco.com/c/en/us/td/docs/telepresence/ix_sw/8_x/admin/guide/ix_8_admin_guide/ix_sw_mntr.htmlQUESTION 25

What is the minimum required number of people to install an IX5000 in one day?A. threeB. fourC. twoD. one**Answer: C**

QUESTION 26What should you do first when the local Touch 10 falsely indicates that content is being shared?A. Power-cycle the

system.B. Close and re-open the share tray.C. Use the Setup wizard to repeat system setup.D. Close and re-open Self View.**Answer: B**

Explanation:CSCur32160 Symptom The share tray on the local Touch 10 still shows that the local side is sharing content, even when content is no longer being shared.Conditions This condition is seen when a presentation is shared on the local side, then is overwritten by a presentation on the remote side. The share tray on the local side is not updated with this information.

Workaround Close and then re-open the share tray (one method is to press the Home button, then press the Share button).

http://www.cisco.com/c/en/us/td/docs/telepresence/ix_sw/8_x/release/notes/ix_release_notes.htmlQUESTION 27What should

you do first when a display shows a black screen instead of presentation content after hot-swapping cables?A. Power-cycle the

system.B. Close and re-open the share tray.C. Use the Setup wizard to repeat system setup.D. Close and re-open Self

View.**Answer: A**

Explanation:CSCuq50609 Symptom While sharing presentation content either during a call, or outside of a call (local presentation), main or auxiliary displays show a black screen, rather than the presentation content. Conditions Display cables were plugged and unplugged while they system was running (known as "hot swapping" the display cables).Workaround Reboot or

power cycle the system. Hot swapping of display cables is not supported.

http://www.cisco.com/c/en/us/td/docs/telepresence/ix_sw/8_x/release/notes/ix_release_notes.htmlQUESTION 28Where is the

option to choose OBTP?A. Booking > Basic Settings> New ConferenceB. New Conference > Booking > Basic Settings > Type

C. Booking > New Conference > Basic Settings > TypeD. Basic Settings > New Conference > Booking**Answer: C**

Explanation:Cisco TMS has incorporated Cisco's One Button to Push - OBTP. As a conference participant you do not need to know any details like phone numbers or which endpoints to dial. This differs from the conference type Automatic Connect. All you need to do with

OBTP's scheduled conference is to press the entry on the CTSs or TC5 conference list that is displayed on screen.An example on

how to book an OBTP conference:1. Go to the Booking > New Conference > Basic Settings pane.2. For Type, select One Button to

Push.3. Select the participants and proceed as usual with other details for your conference.

http://www.cisco.com/c/dam/en/us/td/docs/telepresence/infrastructure/tms/release_note/Cisco_TMS_Release_Note_13-1.pdf

QUESTION 29Which two frame rates can be used by Cisco TelePresence for auxiliary video encoding? (Choose two.)A. 5B. 24

C. 29.95D. 30E. 33F. 60**Answer: AD**

QUESTION 30Which two LDAP configurations are supported in Cisco TelePresence

Manager integration? (Choose two.)A. Multiple Exchange Servers exists within a single forest and a single domain.B. Multiple

Exchange Servers exists within a multiple forest and a single domain.C. Multiple Exchange Servers exists within a single forest

and multiple domains.D. Multiple Exchange Servers exists within a multiple forest and multiple domains.**Answer: AC**

QUESTION 31Which two options are available through the participant icon? (Choose two.)A. List all missed calls.B. Drop a

caller from the call.C. List all participants who were dropped from the call.D. List all participants on the call.E. Add a caller to

the call.**Answer: BD**

Explanation:

http://www.cisco.com/c/dam/en/us/td/docs/telepresence/ix_sw/8_x/user/guide/ix-8-1-ug.pdfpage 8QUESTION 32How can you

change presentation display options during a call?A. Open the share tray and drag the presentation to the desired location.B.

Open the share tray and assign display numbers to each presentation.C. Open the system settings and reconfigure the display

options.D. Open the participant list and drag the presentation to the desired location.**Answer: A**

Explanation:The share tray allows

you to move and duplicate content to and from the main and presentation displays. To show the share tray, tap Share. To add content to the conference, drag the content from the share tray to the presentation area. To remove content from the conference, drag the content from the presentation area to the share tray.

http://www.cisco.com/c/dam/en/us/td/docs/telepresence/ix_sw/8_x/user/guide/ix-8-1-ug.pdf QUESTION 33 Which installation key for the IX5000 is required for IX5000 infrastructure configuration? A. Cisco TMSB. Cisco VCSC. Unified Communication ManagerD. TelePresence MCU
Answer: A QUESTION 34 Which Configuration > Network button registers new or modified settings? A. RestartB. ApplyC. SaveD. Reset
Answer: B Explanation:

http://www.cisco.com/c/en/us/td/docs/telepresence/ix_sw/8_x/admin/guide/ix_8_admin_guide/ix_sw_admin_cfg.html

!!!RECOMMEND!!!1. |2019 Latest Braindump2go 700-070 Exam Dumps (PDF & VCE) Instant

Download: <https://www.braindump2go.com/700-070.html> 2. |2019 Latest Braindump2go 700-070 Study Guide Video Instant

Download: YouTube Video: [YouTube.com/watch?v=0t8nue58PGY](https://www.youtube.com/watch?v=0t8nue58PGY)